

555/565 Pre-Installation Checklist

Thank you for being a Culligan customer! We are excited for your workplace to experience the great-tasting sparkling water from your new 555/565. Before our certified technician can install your machine, the following pre-installation requirements must be completed.

Water Supply

- 3/8" potable water supply terminating in 3/8" ball valve with 3/8" female pipe thread to connect to (ball valve must be accessible for service and installation)
- Minimum water pressure 14.5 PSI, 0.9 gallon per minute minimum flowrate
- Maximum water pressure 51 PSI
 - Must be a dedicated 3/8" water supply line with no other connections
 - Any water line or valve less than 3/8" is not acceptable
- Water shut-off valve must be located at low level with sufficient room for a 12" long fitting to be connected to the shut-off valve.

Electrical

- Dedicated 115 VAC/60Hz/15 amp (standard 3-prong) electrical circuit
- Must be within 5' of machine location; NO EXTENSION CORDS

Countertop Placement

- 1" diameter hole for the water line and CO2 line to the 555/565
 - Culligan technicians are only permitted to drill up to 2" diameter holes through laminate or Corian counters. Any other surface or hole size must be pre-drilled prior to install.

Ventilation

• If installed in an enclosed space, the machine requires 4" of space around the machine for adequate ventilation.

CO₂ Supply

- CO₂ cylinder is on-site
 - If connecting to a bulk or existing CO₂ system, a CO₂ line terminating at 1/4" barbed shutoff valve must be available within 40" of the installation site
 - Minimum CO₂ pressure is 100 PSI

If you have any questions about the installation, call Customer Care at (787) 708-6986

